


## Uninstall TeamBoard Driver/Software

1. To uninstall and install the TeamBoard Driver/Software you must have administrative access to your computer.
2. Go to the Control Panel and select Add/Remove Programs.



3. Scroll down to the TeamBoard Application, then click Change/Remove. Follow the Wizard prompts and you will have successfully uninstalled the TeamBoard Driver/Software.
4. Once complete, reboot the computer.

